




# Качели 2 в 1

## Монтаж, установка, РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ



## ПРЕДУПРЕЖДЕНИЕ

- Внимательно прочитайте всю эту инструкцию, прежде чем начать сборку или использовать эти качели.
- No more than one person on the swing at a time. Multiple users increase the risk of injury.
- Use swing only with mature, knowledgeable supervision.
- The Single swing is suitable for age 3-8 years, with max weight of 99lbs/45kg.
- The nursery swing is suitable for age of 6-36 months, with max weight of 55lbs/25kg.
- Adult supervision required.







Manufactured on behalf of:  
**Crowntec Fitness MFG. LTD.**  
520-1, Sec. 2, Hai Shan Rd., Hai Hu Village, Lu-Chu,  
Taoyuan Hsien, Taiwan, R.O.C.








# SWING PARTS LIST





**ASSEMBLY INSTRUCTION FOR TODDLER SWING**  
**TODDLER SWING FOR CHILDREN 6 MONTHS TO 36 MONTHS**  
**PLEASE RETAIN UNUSED SWING COMPONENTS FOR ASSEMBLY OF JUNIOR SWING**  
**STEP 1 Frame & Swing Seat Assembly**

**STEP 1**  
**SEAT ASSEMBLY**



**STEP 2 Frame & Swing Assembly**





### STEP 3 ANCHORING SWING TO GROUND






**F4** M6 BOLT 58mm (X4)

Take Care When Seating Your Child!  
The child must be secured to the seat  
immediately to avoid any injury.



**Note:** If the soil is hard enough, it may not be necessary to concrete the ground pegs of the baby swing. If the pegs are concreted, additional ground pegs (not provided) will be required for the single swing.



# ASSEMBLY INSTRUCTION FOR JUNIOR SWING

## JUNIOR SWING: FOR CHILDREN 3 -10 YEARS

### STEP 1 Frame & Swing Seat Assembly

**F1**




M8 U-BOLT (X2)

**F5**



M6 BOLT 35mm (x4)



- Remember to attach therope / swing bearing to the U bolt

### STEP 2

#### Frame & Swing Assembly

**F2**




M6 BOLT 42mm (x4)

**F3**



M6 BOLT 52mm (x4)








### STEP 3

#### Anchoring the swing to the ground

**IMPORTANT:** For safety reasons this swing **MUST** be anchored into the ground. We recommend that it is concreted in.



Note: Should the rope become separated from the swing bearing please push it back before continuing to use

